






QUICK START GUIDE

for cyber[®] reaction wheel 2 with starter kit



Thank you for purchasing your cyber[®] reaction wheel 2 with starter kit!

Follow these instructions in numeric order for first commissioning. A detailed instruction can be found in the project planning guide (Download: <https://cyber-motor.wittenstein.de/de-de/download-reactionwheel/>)

<p>1 Packing List</p>	<p>2 Installation on starter kit</p>
<p>cyber[®] reaction wheel 2 1 axis reaction wheel with integrated servo controller</p>  <p>cyber[®] reaction wheel starter kit Startup platform for the cyber[®] reaction wheel 2</p>  <p>cyber[®] reaction wheel assistant Graphical user interface for fast, easy and comprehensive startup and diagnosis</p> 	 <p>Fastening screws $M_A = 0.11 \text{ Nm}$</p> <p>Installation in all 3 axis possible</p> 
<p>3 Establish the power supply</p>	<p>4 Install cyber[®] reaction wheel assistant</p>
<p>Option 1</p>  <p>Option 2</p>  <p>G</p>  <p>Switch to USB PC</p>	 <p>Download cyber[®] reaction wheel assistant</p> <p>https://cyber-motor.wittenstein.de/de-de/download-reactionwheel/</p>

QUICK START GUIDE

for cyber[®] reaction wheel 2 with starter kit

<p>5 Establish a connection</p>	<p>6 First commissioning (speed setting)</p>
<p>1) Open </p> <p>2) Select device ReactionWheel</p>  <p>3) Connect</p> 	<p>1) Open Service motion</p>  <p>2) Select „Continuous“ mode</p> <p>3) Enter</p> <ul style="list-style-type: none"> • Target Velocity • Acceleration and • Deceleration <p>4) Enable drive</p> <p>5) Start rotation by pressing „PLAY“ or „STOP“ to end</p> <p>6) View and/or record status in Monitor (a) or Scope (b)</p> 
<p>7 Prototype integration into ADCS</p>	
 <p> = C-code with functions for control and diagnostics of the reaction wheel</p> <p>A MORE DETAILED INSTRUCTION CAN BE FOUND IN THE PROJECT PLANNING GUIDE</p>	