Mounting kit - Hygienic mounting

Hygienically safe mounting

Our Hygienic Desi^{gn}(i) products have been designed for applications that require maximum cleanability and leak protection. To meet these requirements in a comprehensive approach all the way to the connection of the gearbox, the gearbox must be mounted to the product in a tailor-made and hygienically safe manner. Therefore we have developed special mounting kits to ensure a hygienic connection with maximum process reliability. The sealing parts and screws included in the mounting kits prevent hygienic weak spots and seal cavities on the application side.

HDV and axenia value:

The mounting kit for our HDV and axenia value includes:

- · O-rings to seal the direct contact surfaces between gearbox and machine
- · A suitable stainless steel(i) screw set with screw head seals for assembly to the machine
- · A disc to seal the centering in the output shaft





HDP+:

The hygienic mounting kit for our HDP+ contains:

- · O-rings to seal the direct contact surfaces between gearbox and machine
- \cdot a sealing disc for the final sealing of the flange connection

Advantages for you:

- · Take advantage of the opportunities to save storage capacities by packaging of the mounting material
- · Benefit from a comprehensive solution for maximum process reliability

If you have any questions, please don't hesitate to contact your sales representative or WITTENSTEIN alpha.